




DRAWINGBOARD VI™ USER'S GUIDE



THE DRAWINGBOARD VI FAMILY OF SMALL FORMAT AND
LARGE FORMAT DIGITIZERS



Table of Contents

Introduction	3
Parts Checklist	4
What You Will Need to Use DrawingBoard VI	5
PC Requirements	5
For a USB Installation	5
For an Optional Serial Installation	5
DrawingBoard VI Overview	6
Active Area	6
Menu Strip	6
Indicator Light	6
Transducers	7
Preparing the Large Format DrawingBoard VI	7
Mounting on a Stand	7
Attaching the Accessory Tray or Plan Holder	7
Software Configuration	8
Configuring Non-Wintab Applications	8
Installing the TabletWorks Driver	8
Hardware Configuration	9
USB Connection	9
Optional RS-232 Serial Connection	10
Tablet Power-On	11
Customizing the Tablet	11
Overview of the Menu Strip	11
Selecting a Pre-Programmed Setup	12
Selecting a Custom Setup	13
Tablet Options	14
Recommended Setups for Common PC Software Applications	20
Restoring a Pre-Programmed Setup	24
Learning the Basics	25
Using the Transducer	25
Using the Cursor	25
Using the Pen	25
Learning Basic Movements	26
Clicking and Double-Clicking	26
Dragging	26
Caring for the Tablet and Transducer	27
Cleaning the Tablet	27
Cleaning the Cursor	27
Replacing the Pen Tip	28
Replacing the Cordless Pen Batteries	28
Replacing the Cordless Cursor Batteries	28



Troubleshooting	30
Tablet Checklist	31
Computer Checklist	31
Software Checklist	32
Troubleshooting Chart	33
Returning your Tablet for Repair	34
Repacking for Shipment	34
Parts and Accessories	34
Glossary	35
Regulatory Statements and Warranty	38
Radio and Television Interference	38
Canada	39
European Union Emission Directive	39
European Union WEEE Directive	39
Japan	40
Bescheinigung des Herstellers/Importeurs	40
Limited Warranty for the DrawingBoard VI	41

Introduction

DrawingBoard VI belongs to a class of computer input devices called **graphics tablets**, or **digitizers**. A digitizer is an electronic tablet work surface. The position of a transducer, a handheld cursor or stylus pen, on the work surface of the DrawingBoard VI is converted – digitized – into data for computer processing. Data output from the DrawingBoard VI digitizer is in the form of an X/Y coordinate pair that pinpoints the precise location of the transducer on the tablet surface. By placing a drawing or sketch on the tablet's surface and tracing over it, graphical information can be easily converted into accurate digital information for entry into the computer. DrawingBoard VI digitizers utilize the same Advanced Function Technology that has set the world standard for performance since 1975. These high performance tools are Engineered with a state-of-the-art positioning grid to ensure reliability, performance and quality. Multiple accuracy versions are available to meet specific system requirements.

The DrawingBoard VI family of small and large format digitizers boasts the highest resolution, 12,700 lines per inch, on the market today, unparalleled accuracy and a wide range of sizes, providing the perfect solution when the work demands precision data input, particularly over a large surface area. CAD, GIS, engineering, textile and apparel designers appreciate the variety of cordless and corded cursors and stylus pens available to use with DrawingBoard VI. An integrated mounting channel on the large format frame allows components, such as an accessory tray, to be quickly and easily mounted. The Tabletworks Driver offers programmable



function keys to round out the picture of a powerful, versatile tool that can be configured to meet the needs of any application environment from drawing, animation, presentation graphics and desktop publishing to drafting and mapping. The high-productivity DrawingBoard VI can be used as both a digitizer and a mouse, eliminating the need for multiple devices at your computer.

In order to send data to a digitizing application, DrawingBoard VI must be physically connected to a computer and should be able to transmit data in such a way that the digitizing application recognizes and understands it. Before setting up DrawingBoard VI, you should determine:

- Requirements of the digitizing software application being used
- Whether the digitizing application requires software drivers to communicate with DrawingBoard VI
- Hardware communications connection (USB or serial) being used between DrawingBoard VI and the computer

Parts Checklist

- | | |
|---|-------------------------------|
| ✓ DrawingBoard VI digitizer/tablet | ✓ Universal mounting brackets |
| ✓ Transducer (corded or cordless pen, 4-button or 16-button cursor) | ✓ Accessory Tray |
| ✓ USB cable | ✓ Warranty Sheet |

Optional Equipment

- | | |
|--|----------------|
| ✓ RS-232 serial kit (power supply and cable) | ✓ Versa Table* |
| ✓ Clear overlay* | |

***For Large Format Digitizer Only**



What You Will Need to Use DrawingBoard VI

PC Requirements

DrawingBoard VI is equipped with both a USB and RS-232 serial interface, which requires an optional RS-232 cable and power supply. It is compatible with a majority of industry-standard PCs. TabletWorks Driver is provided by GTCO CalComp and is the only software described in this manual. TabletWorks supports Wintab and TabCon-compatible applications. If you are not sure if Tabletworks is required, please consult with your application vendor.

A USB connection requires the use of a TabletWorks driver, while a serial connection requires the use of a TabletWorks driver and/or a custom application program. After installing the TabletWorks software, DrawingBoard VI will work with **all** Windows-based applications specifically designed for use with digitizers.

For a USB Installation

- Microsoft Windows 7, 8 or 10
- One available USB port
- 10 MB of free disk space
- Application software that accepts digitizer input via the Wintab API or TabCon API


For an Optional Serial Installation

- Microsoft Windows 7, 8 or 10
- One available RS-232C serial communication port (Serial signal levels must conform to EIA RS-232C specifications)
- 10 MB of free disk space
- Application software that directly accepts digitizer input via the computer's RS-232C serial port, or via the Wintab API or TabCon API



DrawingBoard VI Overview

The DrawingBoard VI digitizer (large format shown here) consists of:



Active Area

The drawing area – Active Area – is the portion of the tablet surface designated for digitizing. Its boundaries are marked at each corner by a right-angle crop mark on large format tablets. On small format tablets, the Active Area is delineated by the overlay – not including the menu.

Menu Strip

The Menu Strip is the row of keys located in the lower left corner of the large format tablet and across the top of the small format tablet. You can use the keys to customize your tablet, or to assign macros to Configuration keys for greater productivity.

Indicator Light

The power/proximity LED in the upper right corner of the large format DrawingBoard VI frame or the proximity/configuration light above the Menu Strip on the small format tablet is the Indicator Light. It remains off when the power is on. However, when the transducer is in prox (within the range) of the Active Area, the LED is solid green.



Transducer

Two types of transducers can be used with DrawingBoard VI: pens and cursors. Both are available in corded and cordless versions. The corded transducers receive power from the digitizer. Cordless transducers are powered by batteries. They will go into a battery-saving *Sleep Mode* when no button has been pressed for one to five minutes, depending on the type of transducer being used. To reactivate a sleeping transducer, press one of its buttons.

Cursors

The cursor is similar in appearance to a mouse, except that it has an attached lens with crosshairs for highly accurate detail work. Cursors are available in 4 or 16 button models.

Pens

Each pen corded and cordless are similar in appearance to a ballpoint pen. The pen transducer has three buttons, two on the side of the barrel and one in the pen tip.

Preparing the Large Format DrawingBoard VI

Mounting on a Stand


Visit our Website www.gtcocalcomp.com to see our Recommended Tilt Stand

(Versa Table)

Attaching the Accessory Tray or the Optional Plan Holder

Additional T-Nuts have been included in the perimeter mounting channels on the DrawingBoard VI frame. You can position the Plan Holder or Accessory Tray where it is most convenient for you by attaching it to any one of the available T-Nuts. The following instructions and the graphic below detail the installation of the Accessory Tray.

Simply slide the Tray Rails into the channel and line up the hole in the tray with the hole in the T-Nut. Tighten the Thumb Screw to secure the Accessory Tray.



Software Configuration


Software drivers provide the communication bridge between your digitizing software application and DrawingBoard VI. Install only the drivers necessary for the DrawingBoard VI to work with your application software. If you are not sure which drivers are required, consult with your application vendor.

Configuring Non-Wintab Applications for Optional Serial Interface Only

Many application programs provide configuration information for specific digitizers. If the DrawingBoard VI digitizer is not listed, you can use the configuration for GTCO CalComp by Turning Technologies Digi-Pad Type 5 or Type 5A (T5/T5A), CalComp 9100/9500, or Summagraphics Microgrid III or ID Series.

Installing the TabletWorks Driver

Visit our Website <https://www.gtcocalcomp.com/software-downloads/>


A TabletWorks icon  will display in the System Tray on the Windows Task Bar. Right click on the icon to display the TabletWorks Menu, which provides access to all the TabletWorks features.



Hardware Configuration

When you use the USB interface, no data output configuration is required. When you use the optional serial interface, DrawingBoard VI must be configured to send data in a format that is compatible with the application software. Different applications have different requirements when interacting with a digitizer. Determine if you have not already, which communication connection you will be using – USB or serial.


1. Connect the corded transducer – cursor or pen – to the appropriate jack on the digitizer's Connector Panel. The connector is keyed and will fit only the correct jack. Do not force it.




DrawingBoard VI Connector Panel (large format shown here)

USB Connection

DrawingBoard VI USB port connection is USB 1.1 and 2.0 compatible. When the digitizer is connected to the USB port, Windows will recognize that there is a new device connected. If Windows displays the *Found New Hardware* prompt, follow the onscreen instructions to complete the driver installation.


1. Connect the interface cable to the USB jack on the DrawingBoard VI Connector Panel. The connector is keyed and will fit only the correct jack. Do not force it.
2. Attach the other end of the USB cable to any one of the USB ports  on your computer or USB hub. Turn the power switch on. The digitizer will beep once, indicating it has power.



NOTE: Power is supplied through the USB port.
No additional power source is needed for a USB installation.

Optional RS-232 Serial Connection

1. Connect the RS-232 serial cable to the serial jack on the Connector Panel. The connector is keyed and will fit only the correct jack. Do not force it. Attach the other end to an RS-232 serial port on your computer.
2. Plug the power supply into an AC outlet. Join the power supply to the appropriate jack on the Connector Panel. Turn the power switch on. The digitizer will beep once, indicating it has power.





Tablet Power On

The DrawingBoard VI power switch is located at the rear of the tablet on the Controller Connector Panel. When turned on, the DrawingBoard VI's Indicator light will begin blinking.

If you are using a cordless transducer, turn it on by pressing any button. The Indicator light will glow steadily when the transducer is inside the Active Area of the tablet. When the transducer moves outside the Active Area, the Indicator light will Blink steadily.

Customizing the Tablet

Tailor DrawingBoard VI digitizer and transducer to suit your individual work requirements using TabletWorks. TabletWorks is a Windows program included with the digitizer software that helps you use the full capabilities of your DrawingBoard VI. You can map your digitizer to the screen area and program stylus and cursor buttons with custom macros.

If you have chosen to use the optional serial interface, you will be able to customize the tablet data format and communications parameters using the Menu Strip, described below.

Overview of the Menu Strip for Use with the Optional Serial Interface Only



The Menu Strip is composed of:

Config/Exit Key



The Config/Exit key turns Configuration Mode ON and OFF.

3 Bank Keys



There are three Bank keys: A, B and C. Each bank has a different set of tablet options that are available through Configuration key combinations.

18 Configuration Keys



through



They keys numbered 1-18 can be used as both Configuration and Macro keys. When the tablet is in Configuration Mode, the keys function as Configuration keys. These keys allow you to set specific tablet options by turning different combinations of Configuration keys ON or OFF.

When Configuration Mode is OFF, the keys function as Macro keys. Macros can be recorded only with the TabletWorks software.



3 Save and 3 Restore Keys

The Save and Restore keys work hand-in-hand. They are used to save, or recall/restore, a setup to or from one of three Save Areas. The tablet comes with three pre-programmed setups. You can use these setups directly or overwrite them with your own. The Default Save Key controls the first Save Area. The setup saved to this area is activated whenever you power-up the digitizer. We recommend you save the setup you use most often as *Default*.

Selecting a Pre-Programmed Setup

There are three pre-programmed setups available with DrawingBoard VI:

- GTCO CalComp DP5 High Resolution Binary
- Summagraphics MM 1201
- CalComp 2000 ASCII

These setups are commonly used within software applications as required tablet formats. They are stored in Save Areas *Default*, *2* and *3*, respectively. Check the manual that came with your software package to see if your application requires one of these pre-programmed setups. The *Default* setup is available when you power on the digitizer.

To select one of the other setups:



1. Turn on Configuration Mode by clicking on the **Config/Exit** key.



2. Click on the desired **Restore** key.



3. Click on the **Config/Exit** key again to exit Configuration Mode. The new setup is activated.



The following table lists the tablet options used by the pre-programmed setups.

	Default	Save 2	Save 3
Mode	Run	Track	Point
Baud Rate	9600	9600	9600
Data Bits	8	8	7
Parity	None	Odd	Even
Data Rate	125 pps	150 pps	125 pps
Resolution	1000 lpi	500 lpi	200 lpi
Output Format	Format 23	Format 30	Format 0
Emulation	GTCO TTech DP5 High Resolution Binary	Summagraphics MM 1201 Binary	CalComp 2000 ASCII

Selecting a Custom Setup

You can setup specific tablet options by turning different combinations of Configuration keys ON or OFF. The available tablet options are listed below.

To setup the tablet:



1. Turn on Configuration Mode by clicking on the **Config/Exit** key.



2. Click on the **Bank** key where you need to work (A, B or C).

You can determine which bank you are in by placing the transducer over one of the Bank keys. The Indicator light is on if the Bank is active.



3. Determine whether the **Configuration** keys are ON or OFF by placing the transducer over each key. If the key is ON, the Indicator light is ON
4. Repeat steps 2 and 3 for the remaining Banks as required.



5. After you have completed your setup, save it by clicking on one of the **Save** keys.



6. Exit Configuration Mode by clicking on the **Config/Exit** key.



Clicking on a Save key will **overwrite the pre-programmed setup**. This step may be omitted if the setup is *temporary* for the current session, but the setup will be lost when the tablet is powered off. Only save your setup when you will need it for repeated work sessions.

When you overwrite a pre-programmed setup, see the *Restoring a Pre-Programmed Setup* section for information on restoring the original settings.

Tablet Options

The following sections show the various tablet options available through Configuration keys on the Menu Strip. Follow the procedure described on the previous page, using the keys shown for the option. The circles represent the Indicator light on the tablet:

● = Indicator light ON

○ = Indicator light OFF

Defining operating mode

	Config Exit	A 1-18	1	2
Line			○	○
Point			○	●
Track			●	○
Run			●	●



Setting up increment mode

Config Exit	A 1-18	3	4
None		<input type="radio"/>	<input type="radio"/>
1		<input type="radio"/>	<input checked="" type="radio"/>
5		<input checked="" type="radio"/>	<input type="radio"/>
10		<input checked="" type="radio"/>	<input checked="" type="radio"/>

Turning on prompt mode

Config Exit	A 1-18	5
On		<input checked="" type="radio"/>
Off		<input type="radio"/>

Setting up data rate for CalComp 2000 format

Config Exit	A 1-18	6	7	8
1 pps		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
5 pps		<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>
10 pps		<input type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>
20 pps		<input type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>
40 pps		<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>
75 pps		<input checked="" type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>
100 pps		<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>
125 pps		<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>

Setting up data rate for Summagraphics MM ASCII format

Config Exit	A 1-18	6	7	8
7 pps		<input type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>
20 pps		<input type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>
50 pps		<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>
100 pps		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>



**Setting up data rate for Summagraphics
MM binary format**

	Config Exit	A 1-18	6	7	8
7 pps			<input type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>
25 pps			<input type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>
75 pps			<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>
150 pps			<input type="radio"/>	<input type="radio"/>	<input type="radio"/>

Setting up resolution

Resolutions up to 10,000 lpi are available on the large format tablets for applications that support it.

☒ = Indicator light ON
☐ = Indicator light OFF

	Config Exit	A 1-18	9	10	11
200 lpi			<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>
254 lpi (10 lpmm)			<input type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>
400 lpi			<input type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>
500 lpi			<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>
508 lpi (20 lpmm)			<input checked="" type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>
1000 lpi			<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>
1270 lpi (50 lpmm)			<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>
2540 lpi (100 lpmm)			<input type="radio"/>	<input type="radio"/>	<input type="radio"/>



Setting up format

	Config Exit	A 1-18	12	13	14	15	16
0-CalComp 2000 A			<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
1-CalComp Wedge			<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>
2-Summa ID ASCII			<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>
3-Summa MM 1201 A			<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>
4-CalComp 9100-1			<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>
5-CalComp 9100-2			<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>
6-CalComp 9100-3			<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>
7-CalComp 9100-4			<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>
8-Summa MM 1105 A			<input type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
9-GTCO DP5 ASCII			<input type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>
10-GTCO DP5 ASCII			<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>
11-GTCO MD7 ASCII			<input type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>
12-Hitachi ASCII			<input type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>
13-HiPad ASCII			<input type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>
14-Hitachi ASCII Sign			<input type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>
15-Summa MM 1105 A			<input type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>
16-Summa MM 1105 A			<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
17-Wacom ASCII			<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>
18-Reserved			<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>
19-Reserved			<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>
20-CalComp AFT			<input checked="" type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>
21-Wacom Binary			<input checked="" type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>
22-CalComp Fmt 22			<input checked="" type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>
23-CalComp Hi Res			<input checked="" type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>
24-GTCO DP5 Hi Res			<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
25-GTCO Lo Res Bin			<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>
26-Kurta Serial 1 #3			<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>
27-Hitachi Hi Res			<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>
28-CalComp 2000 Bin			<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>
29-Summa MM 1201 B3			<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>
30-Summa MM 1201 B			<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>
31-MicroGrid II Binary			<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>



Adding line feed

☒ = Indicator light ON

☐ = Indicator light OFF

Config A 17
Exit 1-18

None ☐

Add ☒

Setting up data/stop bits

Config A 18
Exit 1-18

7 ☐

8 ☒

Setting up baud rate

Config B 1 2 3
Exit 1-18

19200 ☐ ☐ ☐

9600 ☐ ☐ ☒

4800 ☐ ☒ ☐

2400 ☐ ☒ ☒

1200 ☒ ☐ ☐

Setting up parity

Config B 4 5 6
Exit 1-18

None ☒ ☐ ☐

Mark ☐ ☒ ☒

Space ☐ ☒ ☐

Even ☐ ☐ ☒

Odd ☐ ☐ ☐

Setting corded frequency

* No longer Applicable

Config B 7
Exit 1-18

Low ☐

High ☒

Using Summagraphics MM or CalComp 2000 commands

Config B 8
Exit 1-18

Use commands ☐

Do not use ☒



Using ESC for 9X00 commands

Config Exit B 1-18 9

Do not use ESC ☐

Must use escape ☒

Sending data out of proximity

Config Exit B 1-18 10

No data out of prox ☐

Send data ☒

Turning on pressure pen data

Config Exit B 1-18 11

Off ☐

On ☒

Turning on pen height data

Config Exit B 1-18 12

Off ☐

On ☒

Turning on pen tilt data

☒ = Indicator light ON

☐ = Indicator light OFF

Config Exit B 1-18 13

Off ☐

On ☒

Turning on pen tilt correction

Config Exit B 1-18 14

Off ☐

On ☒

Setting up CTS line enable

Config Exit B 1-18 18

Off ☐

On ☒

Removing CR on ASCII formats

Config Exit C 1-18 2

CR ☐

No CR ☒



Controlling pen sound




Controlling tablet speaker



Recommended Setups for Common PC Software Applications

The following sections show the **Configuration** key setups for some common PC software packages. Setup the Configuration keys as shown below (see *Selecting a Custom Setup*). The circles represent the Indicator light on the digitizer.



Setting up for ARCINFO

Using CalComp 9100 format:

Config Exit	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18
A 1-18	○	●	○	○	○	●	●	●	●	○	○	○	○	○	○	○	○	○
B 1-18	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C 1-18	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○

Using GTCO DigiPad format:

Config Exit	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18
A 1-18	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
B 1-18	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C 1-18	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○



Setting up for AutoCAD (DOS only)

Using ADI format:

Config Exit	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18
A 1-18	●	●	○	○	○	●	●	●	●	○	○	○	○	○	○	○	○	○
B 1-18	○	○	●	●	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C 1-18	○	○	●	●	○	○	○	○	○	○	○	○	○	○	○	○	○	○

Using CalComp 9100 format:

Config Exit	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18
A 1-18	●	●	○	○	○	●	●	●	●	○	○	○	○	○	○	○	○	○
B 1-18	○	○	●	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C 1-18	○	○	●	●	○	○	○	○	○	○	○	○	○	○	○	○	○	○

Setting up for GeneriCAD

Using CalComp 9100 format:

Config Exit	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18
A 1-18	●	●	○	○	○	●	●	●	●	○	○	○	○	○	○	○	○	○
B 1-18	○	○	●	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C 1-18	○	○	●	●	○	○	○	○	○	○	○	○	○	○	○	○	○	○

Using GTCO DigiPad format:

Config Exit	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18
A 1-18	●	●	○	○	○	●	●	●	●	○	○	○	○	○	○	○	○	○
B 1-18	○	○	●	●	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C 1-18	○	○	●	●	○	○	○	○	○	○	○	○	○	○	○	○	○	○

Using Summagraphics format:

Config Exit	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18
A 1-18	●	○	○	○	○	○	○	●	●	○	○	○	○	○	○	○	○	○
B 1-18	○	○	●	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C 1-18	○	○	●	●	○	○	○	○	○	○	○	○	○	○	○	○	○	○



Setting up for MapInfo (DOS only)

Using CalComp 9100 format:

Config Exit	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18
A 1-18	●	●	○	○	○	●	●	●	●	○	○	○	●	●	○	●	●	●
B 1-18	○	○	●	●	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C 1-18	○	○	●	●	○	○	○	○	○	○	○	○	○	○	○	○	○	○

Using CalComp 2000 binary format:

Config Exit	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18
A 1-18	●	●	○	○	○	●	●	●	●	○	●	○	●	●	●	○	●	●
B 1-18	○	○	●	●	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C 1-18	○	○	●	●	○	○	○	○	○	○	○	○	○	○	○	○	○	○



Setting up for MicroStation (DOS only)

Using CalComp 9100 format:

Config Exit	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18
A 1-18	●	●	○	○	○	●	●	●	●	○	○	○	○	○	○	○	○	○
B 1-18	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C 1-18	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○

Setting up for Timberline

Using CalComp 9100 format:

Config Exit	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18
A 1-18	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
B 1-18	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C 1-18	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○

Using Summagraphics MM 1201 binary format:

Config Exit	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18
A 1-18	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
B 1-18	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C 1-18	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○

Setting up for VersaCAD

Using CalComp 9100 format:

Config Exit	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18
A 1-18	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
B 1-18	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
C 1-18	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○



Restoring a Pre-Programmed Setup

When you save a custom setup to one of the Save areas, the pre-programmed setup will be overwritten. To restore the original setup, place the **Configuration** keys as shown below, following the steps in the *Selecting a Pre-Programmed Setup* procedure. The circles represent the Indicator light on the digitizer.

- = Indicator light ON
- = Indicator light OFF

Restoring Save Default – GTCO DP5 High Resolution

Config Exit	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18
A 1-18	●	●	○	○	○	●	●	●	●	○	●	○	●	●	●	○	●	
B 1-18	○	○	●	●	○	○	○	○	○	○	○	○	○	○	○	○	○	●
C 1-18	○	○	●	●	○	○	○	○	○	○	○	○	○	○	○	○	●	○

Restoring Save 2 – Summagraphics MM 1201 binary

Config Exit	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18
A 1-18	●	○	○	○	○	●	○	○	●	○	○	●	●	●	○	●	●	
B 1-18	○	○	●	○	○	○	○	○	○	○	○	○	○	○	○	○	○	●
C 1-18	○	○	●	●	○	○	○	○	○	○	○	○	○	○	○	○	○	○

Restoring Save 3 – CalComp 2000 ASCII

Config Exit	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18
A 1-18	○	●	○	○	○	●	●	●	○	○	●	○	○	○	○	○	●	○
B 1-18	○	○	●	○	○	●	○	○	○	○	○	○	○	○	○	○	○	●
C 1-18	○	○	●	●	○	○	○	○	○	○	○	○	○	○	○	○	○	○



Learning the Basics

You will find that using your DrawingBoard VI tablet is as easy or easier, than using a mouse. The DrawingBoard VI transducers are more accurate than a mouse, giving you greater control over your movements.

Using the Transducer

The transducer does not need to be in contact with the tablet surface in order for the tablet to sense its presence. It can be detected up to 1/2" above the Active Area. When the transducer is in the zone above the surface of the digitizer, it is referred to as being *in prox*. The Indicator light will go from a blinking green light to a solid green light when the transducer is in prox of, or touching, the tablet's surface. The in prox zone allows you to trace through materials placed on the digitizer's surface, such as drawing or a book. Before using the transducer, be sure that *Sleep Mode* is turned off by pressing a button, or in the case of the pen, touching the tip of the tablet's surface.

Using the Cursor

When you use the cursor, the intersection point of the crosshairs on the lens identifies the point you are selecting. The crosshairs are etched on the bottom of the lens to increase accuracy. For maximum precision, look through the lens from a position directly over it.

Button 0, is used as the pick, or left mouse, button. All other buttons are defined by the TabletWorks software, or through your own software application.

Using the Pen

The pen tip is Button 0 and is used as the pick, or left mouse, button. The lower button is Button 1 and the upper is Button 2.

The functions these buttons provide are defined through the TabletWorks software, or through your own software application.

Click Tip Pen

The click tip pen is available in both corded and cordless versions. It is primarily used for tracing and menu picking. To use the click pen, press down until you feel the tip click.



Learning Basic Movements

The DrawingBoard VI transducers provide all the basic movements of a mouse, including clicking, double-clicking and dragging.

Clicking and Double-Clicking

Clicking is the action of making a selection. You may be selecting a key on the digitizer surface, or making a selection from your computer monitor screen. To click, place the transducer, or move the screen pointer using the transducer, to the item to be selected. Tap the pen or press Button 0 on the cursor. A double-click requires you to quickly tap the pen or press the button two times, while the tool remains in the same place. You can also double-click by pressing the pen or cursor button that has been defined as a double-click button.

Dragging

Dragging is the action of moving the transducer during a selection. To drag, click on an object, but instead of lifting the pen tip or releasing the cursor button, hold it down while moving the transducer, or corresponding object on the screen, to the desired new location.



Caring for the Tablet and Transducer

Follow these precautions at all times to avoid damaging your DrawingBoard VI:

- Avoid discharging static electricity to the tablet.
- Do not place heavy objects on the tablet surface.
- Do not use sharp objects, such as compasses or knives, on the tablet surface.
- Do not use the tablet surface for any purpose other than drawing, tracing or digitizing.
- Do not drill any holes on the digitizer or controller.

Cleaning the Tablet

To clean the tablet's surface, use a soft, non-abrasive cloth. Hardened dirt may be removed with a slightly dampened cloth. Do not clean pencil lines with a soft cleanser or pencil eraser. This may create an undesirable shiny spot on the tablet's surface that cannot be removed.



Do not use abrasive cleaners, acrylic, or lacquer paint thinners – or cleansers with an acetone or solvent base, such as MDC or EDC – on the tablet surface. They will damage the tablet case.

Cleaning the Cursor

To clean the cursor body, use a mild cleanser. Do not spray the cleanser directly on the cursor – instead, dampen a soft cloth with a mixture of water and the cleanser. Clean the cursor reticles with alcohol.



Excessive cleaning can dissolve the filled black crosshair on a reticle.



Replacing the Pen Tip

To replace the pen tip, grasp the tip and pull straight out (see figure). Insert the new tip and press until it clicks into place.



Replacing the Cordless Pen Batteries

The pens require two 393 silver oxide batteries. The average battery life is 200 hours.




**Do not use ZINC AIR batteries as replacement batteries.
They will corrode the electronics of the pen.**



To replace the batteries:

1. Unscrew the pen cap. Hold the pen from the bottom and gently slide off the pen cover to expose the batteries.
2. Remove the old batteries by turning the pen over and gently tapping it, letting the batteries fall into your other hand.
3. Insert the new batteries as they are shown in the figure above (+ towards pen tip).
4. Replace the pen cover and screw the pen cap onto the pen.




Replacing the Cordless Cursor Batteries

The cordless cursor requires two AAA batteries. The average battery life for the cursor is 2,000 hours.

To replace the batteries:

1. Place the cursor face down in the palm of your hand. Use a Phillips screwdriver to remove the two screws located on the bottom of the cursor (see figure). Remove the cursor base.
2. Remove the old batteries from the battery casings.
3. Place the new batteries in the casings, matching the polarity of each battery with the markings on the connector strips (match + to +).
4. Reposition the cursor base. Replace the screws with the Phillips screwdriver.



Troubleshooting

GTCO CalComp wants your experience with DrawingBoard VI to be a successful one. If you ever encounter a problem, please follow the steps below.

1. Review this *User's Guide* to verify you have performed the correct steps.
2. Read the topics below to check for a solution to your problem. Assess the checklists, as well as the Troubleshooting Chart. Keep in mind that the problem could be your computer, display or software, instead of the digitizer.
3. If you still experience an issue, call GTCO CalComp Technical Support at 1.800.220.1137 (in the U.S. or Canada) or email us at support@gtcocalcomp.com. Outside the U.S. or Canada, contact your local GTCO CalComp Dealer. Please have the following information available when you call:
 - Description of the problem
 - Name and version of software package
 - Type of computer being used
 - DrawingBoard VI model and serial number labeled on FCC label on back of tablet
 - Type of transducer

***Tablet Checklist***

- Is the tablet power supply plugged into the digitizer and into a live outlet?
- Is the tablet power switch on?
- Does the Indicator light glow steadily when the transducer is in prox inside the Active Area? Does the Indicator LED Blink when the transducer is outside the Active Area?
- The Indicator light will be off if the transducer has gone into Sleep Mode. Press any button on the transducer to activate it. If the transducer is in the Active Area and the Indicator light remains off, change the transducer's battery.
- Are all cable connections seated properly?
- Is the communications cable (either USB or serial) connected to both the digitizer and the computer? Check that the cable is connected to the serial port specified in your software package.
- Is the transducer cable connected to the digitizer?
- Is the tablet setup according to the software recommendations?
- Are any of the connector cables or receptacles damaged? Check for bent pins, cut insulation and loose wires.

Computer Checklist

- Is the computer plugged into a live outlet? Did you turn on the computer?
- Does the computer work with any of your software? Try one of your other programs.
- Is your software package installed correctly?
- If your communications connection is USB, does the USB port work? If serial, does the serial port work? The only way to test the port without special equipment is to reinstall something that has worked in the past and see if it still works.
- Have there been any recent electrical storms in your area that may have damaged your equipment?



Software Checklist

Does the tablet work with some software?

If your tablet currently works with some software packages, you know that the tablet, USB or serial port and computer work.

- Even if the software package you are trying to install and the software that is working both support the same tablets, it does not always mean that you can use the same tablet settings. The output format may be the same, but the communications protocol, resolution, operating mode and data rate may be different. Check your software's requirements.
- Call the software manufacturer. Perhaps the software package has a problem with another component of your system.

Did the software work in the past?

If the software package worked with the tablet in the past, then the problem lies with the new setup.

- Check all the connectors. Is the tablet still plugged into the same port? If yes, reset the tablet by unplugging and re-plugging the USB connector, or, if you are using serial, unplug and re-plug the power supply. Restart the software.
- Did you reset or power down the computer?
- If you are using a serial connection, during reset and power-on, the computer can send meaningless characters out the serial port and this can disable the tablet. Reset the tablet again.
- Have you installed any new software or hardware? Remove it from your system and see if the problem goes away.
- Did you move any cables?
- Have you updated the software or its drivers?
- Are you loading another mouse driver, or do you have multiple mouse drivers?
- Did you reinstall the software, perhaps after a problem with your hard drive? Double check your installation procedure and the driver you selected.
- Reinstall the software from its master. The program files may have been corrupted.



Troubleshooting Chart

The following table lists common DrawingBoard VI problems, their causes and their solutions.

Problem	Cause	Solution
*Frozen screen pointer	Transducer is in Sleep Mode.	Press any button on the transducer.
	Menu Strip is in Configuration Mode.	If the configuration light is on, click on the Config/Exit key on the Menu Strip.
	Tablet plugged into the wrong serial port on the computer.	Is the serial port being used correctly identified in your software application?
	Tablet not powered correctly.	Check that the power cable is installed correctly.
	Batteries low in transducer.	Replace the batteries in the transducer.
	Software application setup incorrectly.	Check that the tablet is identified in your software application.
Screen pointer appears to shake or jitter	Another device is connected to a COM port that shares the same IRQ as the tablet COM port (<i>i.e.</i> , your tablet is connected to COM1 IRQ4 and your modem is connected to COM3 IRQ4).	Move one of the devices to another COM port. Contact your system manufacturer for assistance in relocating the device.
	Tablet is set too close to the screen monitor.	Move the tablet farther away from the screen.



**Intermittent issue using
Cordless pointer**

Lines jump, can't pic area
On tablet

Check lighting/bad Ballast.
Turn off lights. Try digitizing
Again.

**Unable to use the entire
tablet surface**

Incorrect format selected.

Check your selections in the
Menu Strip.

Software application setup
incorrectly.

Check that the tablet is
identified in your software
application.

Returning your Tablet for Repair

If you believe you have a defective tablet contact Technical Support at 1.800.220.1137 or email us at support@gtcocalcomp.com.

Technical Support will assist you in determining if your tablet is defective and will help you obtain a Return Merchandise Authorization (RMA) number. **Important:** Please do not return your product without first discussing the issue with, and receiving an RMA from GTCO CalComp Technical Support.

Repackaging for Shipment

Whenever you ship electronic equipment, try to ship it in its original packing materials. Place a copy of the RMA in with your Item(s) you are returning and write the RMA number on the package.

Parts and Accessories

Please contact GTCO CalComp at 1.800.220.1137 or email sales@gtcocalcomp.com



Glossary

Accuracy

The similarity of a distance measured by the tablet with the actual distance. When we specify that the accuracy of a tablet is $\pm .010$ inches, we mean that every point in the Active Area is within .010 inches of where it should be.

ASCII

Abbreviation for *American Standard Code for Information Interchange*.

Baud Rate

Rate of speed that data flows between a host computer and the digitizer. It is the number of bits transmitted per second. The lower the baud rate, the slower the speed.

Bit

Basic unit of information in the binary system – either 0 or 1.

Button

Switch on the cursor or pen used to input data.

Byte

Group of eight bits that acts as a single unit of information.

Coordinate Pair

Pair of numbers representing a unique point on the digitizer surface, usually the distance across and up from the tablet origin.

CR

The ASCII Carriage Return character usually added to the end of the X,Y coordinate pairs sent by the tablet (ASCII formats).

Cursor

- 1.) Transducer used to select specific points on the tablet surface.
- 2.) Symbol displayed on the screen marking where the next action will take effect, or where the next character typed from the keyboard will appear.

Data Bits

Each transmission contains 7 or 8 data bits.

Data Rate

Number of coordinate pairs (X,Y) the tablet sends to the computer per second.

**Default**

A value, action or setting that a computer system assumes, unless the user gives an explicit instruction to the contrary.

Drawing Area

Area on the tablet surface intended for digitizing. Referred to as the *Active Area*.

Format

The form in which data is sent from the tablet. DrawingBoard VI tablet can output 32 different formats.

Frequency

Number of waves that pass a fixed point in one second.

Height

See Proximity.

Increment Modes

This mode is used with other operating modes. Data points are sent only if the transducer has moved the required increment distance in either the X or Y direction and has satisfied the requirements of the operating mode. These increment distances are set separately for each axis.

Jitter

Repeatability error of short duration caused by electrical noise.

Key

Portion of the tablet surface available to the user for tablet setup.

Line Feed

Optional character added to the end of an output format that causes the printer to move to the next line, or causes a line to be added on the display screen.

Line Mode

The tablet sends coordinate data points continuously, while the pen tip or a cursor button is depressed, and one additional point when the pen tip or cursor button is released.

LPI

Abbreviation for *lines per inch*. English unit of measurement for resolution measuring the number of separate, distinguishable locations that may be found within the distance of one inch.

**LPmm**

Abbreviation for *lines per millimeter*. Metric unit of measurement for resolution measuring the number of separate, distinguishable locations that may be found within the distance of one millimeter.

Mouse Mode

Operating mode that emulates Microsoft and Mouse Systems mouse drivers. Data constantly transmits when the cursor or pen is on the drawing area of the tablet.

Operating Mode

The conditions that must be met before the tablet sends information to the computer.

Output Format

System of characters used by the DrawingBoard VI tablet for outputting data.

Parity

Type of error detection where a bit is inserted into every character the digitizer transmits. The status of the parity bit confirms that the data was not altered during transmission.

Point Mode

The digitizer transmits one coordinate data point when a cursor button or the pen tip is depressed.

Prompt Mode

The digitizer transmits one coordinate pair each time the computer sends a prompt character to the unit. Prompting can operate with any mode except Mouse mode.

Proximity

Greatest distance above the Active Area that the transducer can be raised and still be sensed by the tablet.

RAM

Abbreviation for *Random Access Memory*, a specific type of memory used by the computer.

Resolution

Distance increment that the tablet outputs in lines/inch or lines/mm.

ROM

Abbreviation for *Read Only Memory*, a specific type of memory used by the computer.

Run Mode

The digitizer transmits coordinate data points continuously, regardless of the status of the cursor buttons or the pen tip. This mode is also called *Stream* by some manufacturers.

**Serial Transmission**

Data transmission protocol where each bit of the data character is sent one at a time over a single circuit. This system saves on transmission circuitry, but is usually slower than parallel transmission.

Stop Bits

One or two stop bits are transmitted with each data byte. They mark a completed transmission.

Track Mode

The digitizer transmits coordinate data points continuously, but only while the cursor button or pen tip is depressed. This mode is also called *Switch Stream* by some manufacturers.

Transducer

Tool used to digitize; it may be either a cursor or pen.

X Direction

Horizontal direction across the face of the tablet.

Y Direction

Vertical distance up and down the face of the tablet.

Regulatory Statements and Warranty***Radio and Television Interference***

The user is cautioned that any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits of a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee the interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.



- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Reorient or coil cables.
- Consult the dealer or an experienced Radio/TV technician for help.

NOTE: Any cables the user adds to the device must be shielded to be in compliance with the FCC standards. Any unauthorized modification to this device could result in the revocation of the end user's authority to operate this device.

Canada

This digital apparatus does not exceed the Class B limits for radio noise emissions from digital apparatus as set out in the radio interference regulations of the Canadian Department of Communications.

Le présent appareil numérique n'émet pas bruits radioélectriques dépassant les limites applicables aux appareils numériques de Classe B prescrites dans le règlement sur le brouillage radioélectrique édicté par le Ministère des Communications du Canada.

European Union Emission Directive

This product is in conformity with the protection requirements of EU Council Directive 89/366/ECC on the approximation of the laws of the Member States relating to electromagnetic compatibility.

This product has been tested and found to comply with the limits for Class B Information Technology Equipment according to CISPR 22/European Standard EN55022. The limits for Class B equipment were derived for typical industrial environments to provide reasonable protection against interference with licensed communication devices.

European Union WEEE Directive

The manufacture of this equipment required the extraction and use of natural resources. It may contain hazardous substances that could impact health and the environment.

- In order to avoid the dissemination of the hazardous substances into the environment and to diminish the pressure on our natural resources, GTCO CalComp encourages you to return this product to the appropriate take-back system facility. These facilities reuse or recycle most of the materials in this equipment in a responsible way.
- The crossed-out wheeled bin symbol below invites you to use these take-back systems.
- If you need more information about the collection, reuse and recycling systems in your area, please contact your local or regional waste authority.
- Further information about the responsible end-of-life management of this and other GTCO CalComp products is available on our website at www.gtcocalcomp.com.



Japan



この装置は、情報処理装置等電波障害自主規制協議会（VCCI）の基準に基づくクラスB 情報技術装置です。この装置は、家庭環境でを使用することを目的としていますが、この装置がラジオやテレビジョン受信機に近接して使用されると、受信障害を引き起こすことがあります。
取扱説明書に従って正しい取り扱いをして下さい。

Bescheinigung des Herstellers/Importeurs

Hiermit wird bescheinigt, dass der/die/das

DrawingBoard VI

(Gerät, Typ, Bezeichnung)

im Übereinstimmung mit den Bestimmungen der

Vfg 1046/1984

(Amtsblattverfügung)

Funk-Entstört ist.

Der Deutschen Bundespost wurde das Inverkehrbringen dieses Gerätes angezeigt und die Berechtigung zur Überprüfung der Serie auf Einhaltung der Bestimmungen eingeräumt.

GTCO CalComp, Inc.

(Name des Herstellers/Importeurs)

Dieses Gerät wurde einzeln sowohl als auch in einer Anlage, die einen normalen Anwendungsfall nachbildet, auf die Einhaltung der Funkentstörbestimmungen geprüft. Es ist jedoch möglich, dass die Funkentstörbestimmungen unter ungünstigen Umständen bei anderen Gerätekombinationen nicht eingehalten werden. Für die Einhaltung der Funkentstörbestimmungen seiner gesamten Anlage, in der dieses Gerät betrieben wird, ist der Betreiber verantwortlich.

Einhaltung mit betreffenden Bestimmungen kommt darauf an, dass geschirmte Ausführungen gebraucht werden. Für die Beschaffung richtiger Ausführungen ist der Betreiber verantwortlich.



Limited Warranty for DrawingBoard VI

GTCO CalComp warrants these products to be free from defects in material and workmanship under the following terms.

Coverage

Parts and labor are warranted for one (1) year from the date of the first consumer purchase for the digitizer tablet, controller, transducers and tablet accessories. Power supply and cables are also warranted for one (1) year. This warranty applies to the **original consumer purchaser only**.

Within the European Union, the warranty period is two (2) years, as mandated by the EU. Contact your local dealer or distributor for additional warranty information.

Warranty information will be captured by the system serial number and confirmed by the reseller's purchase order.

A nominal Diagnostic Fee will be charged after 1 year of use and calculated from the date of original consumer purchase.

Conditions

Except as specified below, this warranty covers all defects in material or workmanship in the products. The following are not covered by the warranty:

1. Any product on which the serial number has been defaced, modified or removed (if applicable).
2. Damage, deterioration or malfunction resulting from:
 - a. Accident, misuse, abuse, neglect, fire, water, lightning or other acts of nature, unauthorized modification for any purpose, unauthorized product modification, or failure to follow instructions supplied with the product.
 - b. Repair or attempted repair by anyone not authorized by GTCO CalComp.
 - c. Any damage in shipment of the product (claims must be presented to the carrier).
 - d. Any other cause which does not relate to a manufacturing defect.

GTCO CalComp will pay all labor and material expenses for covered items, but will not pay for the following:

1. Removal or installation charges.
2. Costs for initial technical adjustments (setup), including adjustment of user controls.
3. Certain shipping charges. (Payment of shipping charges is discussed in the next section of this warranty.)
4. Packaging costs. (Customers should keep their boxes.)

Warranty Service Procedures



1. To obtain service on your GTCO CalComp product, contact the Technical Support Department to receive a Return Material Authorization Number (RMA#) and shipping instructions by calling: 1.800.220.1137
2. Ship the product to GTCO CalComp with the RMA# marked clearly on the outside of the box. Without a clearly marked RMA# on the shipping box, GTCO CalComp reserves the right to refuse the shipment.
3. Although you must pay any shipping charges to ship the product to GTCO CalComp for warranty service, GTCO CalComp will pay the return shipping charges for ground shipment. Other shipping options are available at an additional fee.
4. If GTCO CalComp determines that the unit is not defective within the terms of the warranty, the consumer shall pay the cost of all freight charges, as well as any repair charges.

Technical Support

Web-based Technical Support is available free of charge at: www.gtcocalcomp.com

Telephone Technical Support is available free of charge to the original consumer. Please contact our Technical Support Department at: 1.800.220.1137

Disclaimer of Unstated Warranties

The warranty printed above is the only warranty applicable to this purchase. ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. Assuming the warranty above stated is otherwise applicable, it is expressly understood and agreed that GTCO CalComp sole liability whether in contract, tort, under any warranty, in negligence or other shall be for the repair or replacement of the defective parts and under no circumstances shall GTCO CalComp be liable for special, indirect or consequential damages. The price stated and paid for the equipment is a consideration in limiting GTCO CalComp liability.

Notice

Some states and provinces do not allow the exclusion or limitation of incidental or consequential damages, so the above exclusion may not apply to you. This warranty gives you specific legal rights, and you may have other rights, which vary from state to state, or province to province.



Corporate Headquarters

14557 N. 82nd Street
Scottsdale, Arizona 85260
Sales and Support:
1.800.220.1137

www.gtcocalcomp.com

DRAWINGBOARD VI™

Copyright© 2014 GTCO CalComp by Turning Technologies, Inc.

DrawingBoard VI is a trademark of GTCO CalComp by Turning Technologies, Inc.

All other products and company names are the trademarks or registered trademarks of their respective owners.

The information contained in this document is subject to change without notice. GTCO CalComp by Turning Technologies assumes no responsibility for technical, or editorial errors, or omissions that may appear in this document, or for the use of this material. Nor does GTCO CalComp by Turning Technologies make any commitment to update the information contained in this document. This document contains proprietary information which is protected by copyright. All rights reserved. No part of this document can be photocopied or reproduced in any form without the prior, written consent of GTCO CalComp by Turning Technologies, Inc.

36-01239/37-01099-01 Rev. D