

OIL FILTER CROSS REFERENCE GUIDE

<u>Security #</u>	<u>Fram #</u>	<u>Purolator#</u>	<u>Quaker St#</u>	<u>Pennzoil#</u>	<u>Havoline #</u>	<u>Valvoline#</u>
SO-1072	CH3970	L10085	QS3970	PZ31	T32	VO37
SO-111	PH3387A	L10111	QS3387A	PZ9A	T26	VO16
SO-1218	PH5	L34631	QS5	PZ5	T38	VO56
SO-123	PH3429	L20123	QS3429	PZ10	T23	VO14
SO-16S	PH16	L14670	QS16	PZ34	T35	VO57
SO-173	PH3980	L24011	QS3980	PZ29	T27	VO55
SO-193	PH3950	L10193	QS3950	PZ16	TFC520	VO19
SO-195	PH3600	L20195	QS3600	PZ19	T28	VO23
SO-1A	PH8A	L30001	QS8A	PZ1	T1FS	VO1
SO-241	PH3614	L10241	QS3614	PZ21	T29	VO25
SO2815	PH3569	L30257				
SO-2840	PH4967	L14477	QS4967	PZ39	TFC525	VO41
SO-2861	PH2870A	L20252	QS2870A	PZ35	TFC518	VO43
SO-2867	PH7317	L14620	QS7317	PZ109	TFC529	VO49
SO-2876	PH6607	L14622	QS6607	PZ37	TFC531	VO54
SO-289	PH3985	L14619	QS3985	PZ30	T33	VO35
SO2904	PH7328	L14670				
SO-291	PH3531	L10291	QS3531	PZ18A	TFC516	VO27
SO-33	PH25	L20033	QS25	PZ2	T16	VO3
SO-3593AS	PH3593A	L14459	QS14459	PZ33	TFC520	VO39
SO-373	PH3682	L24457	QS3682	PZ27	TFC524	VO33
SO4386S	PH4386	L14477				
SO-44	PH3506	L14006	QS3506	PZ28	T31	VO58
SO-49	PH30	L20049	QS30	PZ3	T18	VO2
SO-784	PH3766	L30288	QS3766	PZ105	T37	VO46
SO-820	PH2	L24651	QS2	PZ42	T36	VO47
SO824A	CH7329	L20011				
SO825	CH2930	L43056				
SO922	PH3675	L25288				